




CAB PANELS

9200 Short Hood (25 5/8")

P1 	D992107	IN 9200 NO FAIRING 2 P1 LED SS
P1 	D992108	IN 9200 NO FAIRING 2 P1 LED CLEAR SS
P1 	D992121	IN 9200 NO FAIRING 2 P1 LED SMOKE SS
No Light	D992117	IN 9200 NO FAIRING (2) P1 NO LIGHTS SS
Blank	D992011	IN 9200 NO FAIRING BLANK SS





D992101





D992105

9400 (33 5/8")

P1 	D992103	IN 9400 NO FAIRING 3 P1 LED SS
P1 	D992104	IN 9400 NO FAIRING 3 P1 CLEAR LED SS
Blank	D992001	IN 9400 NO FAIRING BLANK SS



9400 With Block Plug

P1 	D992105	IN 9400 NO FAIRING W/PLUG 3 P1 LED SS
P1 	D992106	IN 9400 NO FAIRING W/PLUG 3 P1 LED CLEAR SS
Blank	D992116	IN 9400 NO FAIRING W/PLUG (3) P1 NO LIGHTS SS



9300 (44")

P1 	D992109	IN 9300 3 P1 LED SS
P1 	D992110	IN 9300 3 P1 LED CLEAR SS
No Light	D992118	IN 9300 (3) P1 NO LIGHTS SS
Blank	D992007	IN 9300 BLANK SS



9300 With Block Plug

P1 	D992111	IN 9300 W/PLUG 3 P1 LEDSS
P1 	D992112	IN 9300 W/PLUG 3 P1 LED CLEAR SS
No Light	D992119	IN 9300 W/PLUG (3) P1 NO LIGHTS
Blank	D992008	IN 9300 W/PLUG BLANK SS

9900 (Internal Cans use 9300 Cabs - Otherwise use these - 51")

P1 	D992101	IN 9900 3 P1 LED SS
P1 	D992102	IN 9900 3 P1 LED CLEAR SS
No Light	D992115	IN 9900 (3) P1 NO LIGHTS SS
Blank	D992010	IN 9900 BLANK SS

9900 With Block Plug

P1 	D992113	IN 9900 W/PLUG 3 P1 LED SS
P1 	D992114	IN 9900 W/PLUG 3 P1 LED CLEAR SS



Available in
Paintable!

D992105 & D992106 & D992101

9000 SERIES SLEEPER PANELS CME

51" Sleeper Panel CME

P1 	D982109	IN 9000 SERIES 51" CME 3 P1 LED SS
P1 	D982110	IN 9000 SERIES 51" CME 3 P1 LED CLEAR SS
No Light	D982111	IN 9000 SERIES 51" CME (3) NO LIGHTS SS

72" Sleeper Panel CME




P1 	D982101	IN 9000 SERIES 72" CME 4 P1 LED SS
P1 	D982102	IN 9000 SERIES 72" CME 4 P1 LED CLEAR SS
No Light	D982107	IN 9000 SERIES 72" CME (4) P1 NO LIGHTS SS
Blank	D982001	IN 9000 SERIES 72" CME BLANK SS

9000 SERIES SLEEPER PANELS RME



51" Sleeper Panel RME

P1 	D982105	IN 9000 SERIES 51" RME 3 P1 LED SS
P1 	D982106	IN 9000 SERIES 51" RME 3 P1 LED CLEAR SS
No Light	D982108	IN 9000 SERIES 51" RME (3) P1 NO LIGHTS SS

72" Sleeper Panel RME

P1 	D982103	IN 9000 SERIES 72" RME 4 P1 LED SS
P1 	D982104	IN 9000 SERIES 72" RME 4 P1 LED CLEAR SS
P1 	D982113	IN 9000 SERIES 72" RME 4 P1 LED SMOKE SS
No Light	D982112	IN 9000 SERIES 72" RME (4) P1 NO LIGHTS SS
Blank	D982002	IN 9000 SERIES 72" RME BLANK SS

9000 SERIES EXTENSION PANELS

P1 	D962101	EXT PANEL PR IN 9000 1 P1 LED SS
P1 	D962102	EXT PANEL PR IN 9000 1 P1 LED CLEAR SS
No Light	D962103	EXT PANEL PR IN 9000 (1) P1 NO LIGHTS SS
Blank	D962002	EXT PANEL PR IN 9000 BLANK SS



D962101



D962102




Available in
Paintable!

D982105 & D982106 & D962101

9900i ACCESSORIES

9900i With Lower Fairings

P3		D742305	IN 9900i FRONT W/FAIRING 5 P3 LED SS
P3		D742306	IN 9900i FRONT W/FAIRING 5 P3 LED CLEAR SS
2"		D742006	IN 9900i FRONT W/FAIRING 5 RD SS
No Light		D742005	IN 9900i FRONT W/FAIRING (5) RD NO LIGHTS SS



D131001

Control Panel Trims

D131002	CONTROL PANEL TRIM EA IN 9900 IGNITION SS
D131001	CONTROL PANEL TRIM EA IN 9900 W/ ABS SWITCH SS

Tool & Battery Box Cover

D652001	IN 9300, 9900 '90+ BLANK SS
---------	-----------------------------



D071001



D542101

HVAC Intake Cover

D071002	HVAC INTAKE COVER EA IN 9900 SS
---------	---------------------------------



D071002

9300 ACCESSORIES

Fender Guards

D822001	FENDER GUARD PR IN 9300 SS
---------	----------------------------





D822001



D542101

Lower Step Panels

P1		D542101	IN 9300, 9900 4 P1 LED SS
P1		D542102	IN 9300, 9900 4 P1 LED CLEAR SS
No Light		D542103	IN 9300, 9900 (4) P1 NO LIGHTS SS

Tool & Battery Box Cover

D652001	IN 9300, 9900 '90+ BLANK SS
---------	-----------------------------



D652001