


CAB PANELS

P1 	C992102	FL CENTURY/COLUMBIA 3 P1 LED SS
P1 	C992103	FL CENTURY/COLUMBIA 3 P1 LED CLEAR SS
No Light	C992110	FL CENTURY/COLUMBIA (3) P1 NO LIGHTS SS
Blank	C992008	FL CENTURY/COLUMBIA BLANK SS





SLEEPER PANELS CME

48" Sleeper Panel CME

P1 	C982133	FL 58" CENTURY/COLUMBIA CME 3 P1 LED SS
P1 	C982134	FL 58" CENTURY/COLUMBIA CME 3 P1 LED CLEAR

70" Sleeper Panel CME

P1 	C982110	FL 70" CENTURY/COLUMBIA CME 4 P1 LED SS
P1 	C982107	FL 70" CENTURY/COLUMBIA CME 4 P1 LED CLEAR SS
No Light	C982131	FL 70" CENTURY/COLUMBIA CME (4) P1 NO LIGHTS





SLEEPER PANELS RME



48" Sleeper Panel RME

P1 	C982135	FL 48" CENTURY/COLUMBIA RME 2 P1 LED SS
P1 	C982136	FL 48" CENTURY/COLUMBIA RME 2 P1 LED CLEAR SS

58" Sleeper Panel RME

P1 	C982111	FL 58" CENTURY/COLUMBIA RME 3 P1 LED SS
P1 	C982112	FL 58" CENTURY/COLUMBIA RME 3 P1 LED CLEAR
No Light	C982130	FL 58" CENTURY/COLUMBIA RME (3) P1 NO LIGHTS
Blank	C982010	FL 58" CENTURY/COLUMBIA RME BLANK SS



70" Sleeper Panel RME

P1 	C982106	FL 70" CENTURY/COLUMBIA RME 4 P1 LED SS
P1 	C982105	FL 70" CENTURY/COLUMBIA RME 4 P1 LED CLEAR
No Light	C982132	FL 70" CENTURY/COLUMBIA RME (4) P1 NO LIGHTS
Blank	C982003	FL 70" CENTURY/COLUMBIA RME BLANK SS





EXTENSION PANELS

21"

P1 	C962102	FL CENTURY/COLUMBIA 21" 1 P1 LED SS
P1 	C962101	FL CENTURY/COLUMBIA 21" 1 P1 LED CLEAR SS
No Light	C962111	FL CENTURY/COLUMBIA 21" (1) P1 NO LIGHTS SS
Blank	C962003	FL CENTURY/COLUMBIA 21" BLANK SS







26"

P1 	C962107	FL CENTURY/COLUMBIA 26" 2 P1 LED SS
P1 	C962107	FL CENTURY/COLUMBIA 26" 2 P1 LED CLEAR SS
No Light	C962112	FL CENTURY/COLUMBIA 26" (2) P1 NO LIGHTS SS
Blank	C962008	FL CENTURY/COLUMBIA 26" BLANK SS



Without Side Fairings Only

SUNVISORS

P1		C731105	FL C/C/C 2 BOLT DROPPED 5 P1 LED 17" SS
P1		C731106	FL C/C/C 2 BOLT DROPPED 5 P1 LED CLEAR 17" SS
P1		C731107	FL C/C/C 2 BOLT STD 5 P1 LED 13 1/2" SS
P1		C731108	FL C/C/C 2 BOLT STD 5 P1 LED CLEAR 13 1/2" SS
P1		C731110	FL C/C/C 3 BOLT DROPPED 5 P1 LED 17" SS
P1		C731111	FL C/C/C 3 BOLT DROPPED 5 P1 LED CLEAR 17" SS



Sunvisor Side Cover

C732001	FL CENTURY / COLUMBIA / CORONADO RME SS
C732002	FL CENTURY / COLUMBIA / CORONADO CME SS



ACCESSORIES


Window Trim Chop Top

C572003	FL CENTURY/COLUMBIA CAB 6" SS
C572004	FL CENTURY/COLUMBIA CAB 7" SS



Side Scuff Panel

C703003	LH FL CENTURY FRONT '01+ SS
C703004	LH FL CENTURY FRONT '01+ W/PLUG SS
C704003	RH FL CENTURY FRONT '01+ W/PLUG SS
C704004	RH FL CENTURY FRONT '01+ SS



Call us if you don't see what you're looking for!

1-888-789-2550